
OSSABEL

REQUIREMENT OF A PRESERVATIVE TREATMENT

Against dry wood borer attacks:	Requires appropriate preservative treatment
In case of temporary humidification risk:	Requires appropriate preservative treatment
In case of permanent humidification risk:	Use not recommended

DRYING

Drying rate:	Normal to slow
Risk of distortion:	Slight risk
Risk of casehardening:	No
Risk of checking:	Slight risk
Risk of collapse:	No

Note: Must be dried carefully in order to reduce defects.

SAWING AND MACHINING

Blunting effect:	High
Sawteeth recommended:	Stellite-tipped
Cutting tools:	Tungsten carbide
Peeling:	Good
Slicing:	Not recommended or without interest
Note:	Some difficulties in presence of interlocked grain.

ASSEMBLING

Nailing / Screwing:	Good
Gluing:	Correct

END-USES

Main known end-uses; they must to be implemented according to the code of practice.

Important remark: some end-uses are mentionned for information (traditional, regional or ancient end-uses).

Veneer for interior of plywood
Veneer for back or face of plywood
Formwork
Interior joinery
Interior panelling
Boxes and crates
Blockboard
Fiber or particle boards
Light carpentry
Glued laminated
Wood frame house
Seats
